

12-01056 - CESSNA SEAT RAIL GAUGE



Cena brutto	194,19 zł
Cena netto	157,88 zł
Numer katalogowy	21677878
Kod producenta	12-01056
Kod EAN/Wewnętrzny	5900073764104

Opis produktu

These seat rails have only pilot holes drilled in the rail base allowing the installer to exactly match the aircraft floor rivet pattern. The manufacturer discovered while installing and developing our replacement seat rails that the seat rail attachment hole pattern was not consistent from aircraft to aircraft. Even small inconsistencies in the hole locations in the aircraft floor make installation of new seat rails very difficult. For this reason, all these seat rails have only a few smaller pilot attachment holes drilled at the factory. This allows the installer to precisely locate the attachment holes to match the holes in the aircraft floor. All special sized or machined attachment holes are factory machined to finish dimensions. It is necessary to install all required fasteners when seat rails are installed.

After studying countless worn and failed seat rails these rails were designed with 15% more metal in critical areas. The result is more crack resistant, durability, strength and longer life.

Installation Tip: The aircraft floor is subject to corrosion from moisture under the seat rails, be sure to remove and treat any corrosion before installing the new seat rails.

Model	Serial Number	PN Inboard LH	PN Outboard LH	PN Outboard RH
150A,B,C,D,E,F*	15059019 thru 15063059	05-00346	05-00345	05-00345
F150F*	F1500001 thru F1500029	05-00346	50-00345	05-00345
150F*	15063060 thru 15063735	05-00348	05-00347	05-00347
F150F*	F1500030 thru F1500067	05-00348	05-00347	05-00347
150F*,G,H,J,K,L	15063736 thru 15072628	05-00328	05-00327	05-00327
A150K,L	A1500001 thru A1500276	05-00328	05-00327	05-00327
F150G,H,J,K,L	F1500068 thru F1500738	05-00328	05-00327	05-00327
FA150K,L*	FA1500001 thru FA1500120	05-00328	05-00327	05-00327
FRA150L*	FRA1500121 thru FRA1500166	05-00328	05-00327	05-00327
150L*	15072629 thru 15073658	05-00329	05-00341	05-00329
A150L*	A15000277 thru A15000342	05-00329	05-00341	05-00329
F150L*	F15000739 thru F15000863	05-00329	05-00341	05-00329
150L*,150M	15073659 thru 15079405	05-00344	05-00342	05-00343
A150L*,M	A1500343 thru A1500734	05-00344	05-00342	05-00343
F150L*,M	F1500864 thru F1501428	05-00344	05-00342	05-00343
FRA150L*,M	FRA1500167 thru FRA1500336	05-00344	05-00342	05-00343
152	15279406 thru 15286033	05-00344	05-00342	05-00343
A152	A1520735 thru A1521049	05-00344	05-00342	05-00343
F152	F15201429 thru F15201980	05-00344	05-00342	05-00343
FA152	FA1520337 thru FA1520425	05-00344	05-00342	05-00343
170,170A,170B	18000 thru 27169	05-00331	05-00332	05-00331
172,172A,B,C	28000 thru 17249544	05-00365	05-00367	05-00368
172D,E	17249545 thru 17251822	05-00354	05-00352	05-00353
F172D,E	F1720001 thru F1720085	05-00354	05-00352	05-00353
FP172	FP1720001 thru FP1720003	05-00354	05-00352	05-00353
172F,G,H,I,K*	1725183 thru 17258656	05-00355	05-00352	05-00353
F172F,G,H*	F17200086 thru F17200739	05-00355	05-00352	05-00353
FR172E,F,G*	FR17200001 thru FR17200190	05-00355	05-00352	05-00353
172K*	17258657 thru 17259223	05-00359	05-00357	05-00358

F172H*	F17200740 thru F17200754	05-00359	05-00357	05-00358
FR172G*	FR17200191 thru FR17200225	05-00359	05-00357	05-00358
172L	17259224 thru 17260758	05-00351	05-00338	05-00339
F172K,L	F17200755 thru F17200904	05-00351	05-00338	05-00339
FR172H	FR17200226 thru FR17200350	05-00351	05-00338	05-00339
172M,N*	17260759 thru 17272884	05-00362	05-00363	05-00364
R172K*	R1722200 thru R1723199	05-00362	05-00363	05-00364
F172M,N*	F17200905 thru F17201909	05-00362	05-00363	05-00364
FR172J,K	FR17200351 thru FR17200655	05-00362	05-00363	05-00364
172N*,P*,Q	1727885 thru 17276516	05-00415	05-00414	05-00415
R172K*	R1723200 thru R1723454	05-00415	05-00414	05-00415
F172N*,P*	F17201910 thru F17202238	05-00415	05-00414	05-00415
FR172K*	FR17200656 thru FR17200675	05-00415	05-00414	05-00415
R172K*	R1722000 thru R1723199	05-00362	05-00363	05-00364
FR172K*	FR17200591 thru FR17200655	05-00362	05-00363	05-00364
172RG	172RG0001 thru 172RG1191	05-00415	05-00414	05-00415
P172	P17257120 thru P17257188	05-00354	05-00352	05-00353